



## SS-129 FLASH-HEAD COMPONENT LAYOUT



## SS-129 FLASH-HEAD PARTS LIST

ITEM #	DESCRIPTION	PART #
FH1	Flashhead Assy. Complete (Replacement)	277-4045E
FT1	Flashtube Assembly	277-2818
B1	Base Assembly	ML-300B
G1	Lens Gasket, Upper Assembly	77-672072
G2	Gasket, Lower Assembly	77-4103G
GL1	Globe Assembly	77-3464
GL1	Globe Assembly With Metal Vent Hood	30210118-00
HD1	Globe Hold Down Clip	3411072
LH1	Flashtube Socket Assembly	77-4130
S1	Switch, Flash-Head Interlock	77-2644
TB1	Terminal Block Complete	77-2556
T1	Transformer, Trigger	77-3669



VIEW A-A

