


SS-111 STROBE IV

SS-111 PARTS LIST




COMPONENT LAYOUT

ITEM #	DESCRIPTION	PART #
C1	Capacitor, Resonate 4uf (77-2014)	77-3911
C2	Capacitor, Night Mode 4uf	77-2795
C3	Capacitor, Twilight Mode 20uf	77-2796
C4&C5	Capacitor, Day 100uf 2.5KV	77-2797
CR1	High Voltage Module	77-2732
F2, F7	Fuse 3.2Amp for 480VAC	77-2041
F2, F7	Fuse 6Amp for 240VAC	77-1167
F2, F7	Fuse 10Amp for 120VAC	77-2040
F1, F3-F6	Fuse 1Amp	77-2365
K1	Relay, Interlock	77-2878
K2-K3	Relay, Mode & Bleed	77-2013
K4	Relay, Interlock	77-2710
LA1-LA2	Lightning Arrestor Assembly	77-4139
PCB1	Printed Circuit Motherboard	277-2608
PCB2	Printed Circuit Trigger Control	277-2605
PCB3	Printed Circuit Fault TX 1-24	277-2728
PL1	Power Indicator Lamp	77-2029
R1, R4	3K Ohm 40W Resistor Assembly	277-2998
R2	20 Ohm 40W Resistor Assembly	277-2928
R3	100 Ohm 70 Watt Resistor	277-2929
S1	Switch Interlock, Power	77-2644
S2	Switch Mode, Remote/Local	77-2668
S3	Switch Rotary, Mode Control	77-2667
S1-S3	Mode/Interlock Switch Assembly	277-3521
T1	Transformer Power 60Hz	77-2008

SS-107 PARTS LIST

SS-107/ FLASHHEAD COMPONENT LAYOUT



COMPONENT LAYOUT

S1	Switch Interlock, Power	77-2102
T1	Transformer Tigger	277-2961
TB1-TB2	Terminal Block Kit	77-2962
V1	Flashtube Assembly	277-2123
V2	Flashtube Socket Assembly	277-2292