


FTB-324 Parts Diagram



FTB-324 Parts List

ITEM	DESCRIPTION / OEM PART #
C3	Burst Capacitor, 1uF, 6848202
C4	Tuning Capacitor, 3uF, 6577903
C2B	Capacitor, 40uF, 6386503
C2A, C2C, C2D	Day Capacitor, 70uF, 6720401
BR1	Diode Bridge, 6902806
FT101	Flash Tube, Lower, 8384329
FT102	Flash Tube, Upper, 8384308
F5, F6	Fuse, 4900337
F4	Marker Fuse, 4900345
F1, F2	Power Fuse, 4901931
L1	Burst Choke, 4850601
PCB2	High Voltage Rectifier Board, 8458005 Timing &
PCB1	Trigger Board, 24740xx

ITEM	DESCRIPTION / OEM PART #
PCB1	Trigger Board for Auto Dialer Pro,
PCB4	Sense Module, 2811101
LS1	Telephone Line Surge Suppressor, 2865301 High Voltage
HV	Warning Lamp, 4902317 Bleed Resistor, 6900541
R1	Burst Resistor, 6900532
R2	Marker Relay, 4902617
K5	Discharge Relay, 120V, 8328802
K3	Mode Relay, 24V, 8328801
K2	Interlock Switch, 4901220
S1	Suppressor, 120V, MOV, 8336702 Coupling
VR1	Transformer, T102, 8336702 Power Transformer (-43E),
T3	8841201 Trigger Transformer, 8288201
T1	Resistor Network, 8403407
T101	Resistor Network, 8403403
RC102	Photocell, Resistive, 1855001
RC101	